

**/**|'

X

S


 $( \in \mathfrak{S}$ 



# **User Manual** Scrib3D Advanced

For the best user experience. please read this manual completely before usage.

www.Scrib3Dpen.com



# **Product Overview**



## **Getting Started**

#### 1. Power On

Plug the USB power cord into the power adapter and connect it to an outlet. Plug the other end of the power cord into your pen. (Note: this 3D Pen can be used with a 3rd party power bank with at least 2 Amps output)

#### 2. Select the Filament

"ABS" or "PLA" will show on the LCD SCREEN, you can use the temperature ADJUSTER buttons to select a mode. Choose a mode that corresponds with the type of plastic you are using. (Note: Using the wrong plastic will make for a poor experience and possibly damage your pen)

#### 3. Temperature Settings

Press the FORWARD button to activate the selected mode. You can use the TEMPERATURE ADJUSTER buttons to fine tune the temperature depending on need and desired usage. The temperature ranges are ABS: 180-210°C and PLA: 160-180°C.


#### 4. Filament Loading & Drawing in 3D

Once the desired temperature has been reached the LED on the pen will turn green. You can click the FORWARD button. Straighten the end of the filament you wish to use and load it into the FILAMENT LOADER while the pen is running. Once plastic starts extruding you are ready to start creating in 3D!


#### 5. Changing Colors

To change colors, press and hold the REVERSE button for 5 seconds. The filament will automatically start to retract out of the back of the pen.






The Display will flash either ABS or PLA until the Forward Button is pressed to chose a mode. Then the screen will show desired temperature and current temperature. The temp LED will remain red while the pen is heating up. Once it has reached temp it will change to Green. Then you can draw. You can adjust the temperature at any time but to change from ABS to PLA unplug the pen and plug it back in.



Once the temperature indicator Light has changed from red to green you can load filament into the 3D pen. Straighten the filament at the end. Press and hold the Feed Button. Push the filament into the pen until you can feel it pulling it into the pen.

1 Scrib3D ADVANCED Pen PLA Filament

5V 2Amp



Snip those tips! When you change plastic or before you insert a new strand make sure the filament has a flat surface so it can push the previous filament. Failure to cut the end off the plastic can result in jams or pens not extruding. Check out tips on how to solve such issue on page 6.

- We recommend only using the Reverse button when removing and changing filament. If only partially withdrawn, filament can swell in the pen and create jams. If this happens, fully withdraw the filament and cut the swollen part off.
- Filament quality varies greatly. We always recommend using Scrib3D filament, and storing it in a sealed and dry location.



Plastic may continue to ooze slightly after the pen stops. This is more pronounced with PLA. This is a common Phenomenon (i.e. glue guns and 3D printers). If you see this happening, slightly decrease the temperature.



**Temperature Tuning:** 

1. If when using the pen you see the plastic

bubbling or you hear a crackling noise coming

from the plastic your temperature might be too

high. Try lowering it 5~10°C and see if that helps.

2. Filament should come out smooth and with

small bubbling.

out much bubbling but it is normal to have some

3. While some plastics like PLA are more prone to

the pen to help mitigate this. Also check that you

oozing, if you find that your oozing a lot of

are using the correct filament setting

the temperature is too low increase the

temperature by 5~10°C.

plastic you can turn the temperature down on

4. If the filament color looks dim and dark and

you can hear the motor struggling. This means

For more help getting started, tips and tricks, trouble shooting and to learn more check out our website www.Scrib3dPen.com or our youtube channel (scan the QR code).

### Troubleshooting:

Here are some common problems and possible solutions to these issue. If you can't resolve the issue please reach out to our customer service by email us at help@Scrib3Dpen.com

Problem	Reasons	Solution
Power indicator Light will not turn on	Issue with the AC adapter or plug	Replace the AC adapter with another: 5v, 2A, 3.8mm barrel center + adapter The pen's electronics need servicing please contact help@Scrib3Dpen.com if the pen is under warranty
	Issue with the electronics of the pen	
	Issue with the power socket of the pen	
Red and Green indicator light flashing	Low-power adapter or power bank	Change power bank or adapter to one that has a 2 Amp output
Nothing is coming out of the nozzle	The temperature is not high enough or the wrong mode for plastic was selected	Check mode the pen is in is correct of the plastic you are using. You can also try adjusting the temp manually
	Filament has stripped ie. a chunk has been taken out of the filament and the drive system can't push it anymore	Reverse the filament out of the pen. Cut off the damaged portion and throw it away and try again
	Filament won't go in	Make sure the filament has a flat surface on the end going into the pen
	No motor noise	Possible issue with the electronics or the motor please contact us at help@Scrib3Dpen.com
Pen not heating up	Problem with the heating element/nozzle	Replace the nozzle. See Scrib3Dpen.com for more infe
Motor is struggling	Could be an issue with the filament inside	Reverse out the filament. Cut off any swollen or deformed parts and cut a new end before reinserting.
"ERR" displayed on the screen	Temperature is too high for the mode you are in / or the nozzle is loose	Unplug the pen and let it pen cool down for approximately 3 mins / or try to push the nozzle back into place. If issue persists, reach out to customer service: help@scrib3dpen.com

NOTE: Your pen will go into sleep mode after being inactive for 5 minuts (as a safety feature). Click any button to wake it up and restart the heating sequence. FCC Statement: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful in-terference, and (2) this device must accept any interfer-ence received, including interference that may cause undesired operation.

CAUTION: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

· Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

• You are cautioned that any changes or modifications not expressly approved in this manual could void the user's authority to operate the equipment.

CAUTION: This Class B digital apparatus complies with Canadian ICES-003.

CAN ICES-3 (B)/NMB-3(B)

# **ISSUES?**

SERBID

Before returning to the retailer see if we can help



Need more help? Contact us help@SCRIB3dPen.com